

Lite-Site Fence Kit INSTALLATION INSTRUCTIONS

Fencing should be installed after the base frame installation is complete and the concrete ballast has been added. The monopole should be installed before the fencing kit if possible.

Read through the entire installation procedure before starting!

Extra hardware is supplied. Bill of material with quantities of components and hardware is supplied. Check that all items are present before starting installation.

The tools required to assemble the Lite-Site Base Frame are:

- Socket wrenches up to 3/4"
- Impact driver

Each Fence panel and Gate are the same size as the ballast block. Determine where the compound access will need to be and designate that entry as the stair / gate access.

Center the Fence Panels on top of each ballast block that is NOT designated for the compound entry panel so the welded plate fits snug against the side and top of the ballast block. There should be roughly 1/2" on each side of the fence panel to the edge of the ballast block. Drill through the plate into the ballast and secure with the bits / hardware provided. Repeat this process for each additional Fence Panel.



Attaching the Gate

Determine what side of the entry the gate will swing and place hinges accordingly.

Mount the male hinge on the Fence Panel about 12" from the bottom of the lowest cross member while hinge is facing upwards. Note the measurement from the bottom of the lowest cross member to the top side of the hinge. Mount the female size of the hinge on the Gate Panel and measure from the bottom of the cross member. Repeat the process for the top hinge with the male side facing downward. Leave the female portion of the hinge loose on the gate. Set the bottom hinge in place. Slide up the loose upper hinge to fit and snugly tighten bolts.

Install latch on opposite side. Hinges may need to be twisted in order for the gate to latch properly. Once the gate functions, tighten all the hinge bolts.



Setting Stairs.

The preformed concrete access stairs are a drop in place unit. The handrailing of the stairs needs to line up with the Fence Panel vertical support closest to the gate latch.

Install the Brace Bands on each panel near the upper most cross member. Use the carriage bolts and nuts provided to secure the brace bands together. Each section of Fence Panel will be secured via Brace Bands to the adjoining Fence Panel.

